



QUICK-STEP®



Step 1

Install your underlay.



Step 2

Install your watertight floor.
Provide an expansion gap (8 to 10 mm) between walls and floor.



Step 3

Install a **foamstrip** between the wall and your floor.



Step 4

Apply the **hydrokit** on top of the foamstrip.



Step 5

Install the skirting with the **hydrostrip** and finish up.